



# Smart Pet Fountain



## Quick User Guide

### Content

Please read this manual carefully before use to ensure the safe use of pet water dispenser.



Pet Fountain (subject to the actual product)



User manual



Adapter X1





Anti-biting power cord X1

List of accessories (subject to the actual product)

### Product introduction

#### Structure introduction



### Operation guide

#### First usage

1. Take out pet fountain and accessories.
2. Simply clean the water storage top cover, the inner wall of the water storage bucket and the filter element tank.
3. After soaking the filter element in clean water for 2 minutes, insert it into the filter element slot at the bottom of the top cover.
4. Take out the power adapter and insert it into the USB power port at the bottom of the fuselage.
5. Short press the button on the front of the fuselage to turn on or off the water dispenser function, long press to restore the factory settings and enter the network distribution state (the network indicator flashes).


#### Binding Smart Life APP

##### APP download and installation

Scan the QR code below or the package QR code to download the Smart Life APP and complete the installation.




### Bluetooth Connection




1. Turn on the phone's Bluetooth & Location function.
2. Open App, App will automatically search for devices


Open the APP and follow the steps in the picture to connect




### Normal Connection




Open the APP and follow the steps in the picture to connect




### Pet water dispenser APP interface



### Schematic diagram of adding water to pet water dispenser



1. Lift the top cover.




2. Fill the water tank with water


Warning: Never use hot or boiled water!

### Clean Instruction


It is recommended to wash at least once a week to remove dirt and hair, and to change the water thoroughly to prevent the filter tank from clogging and causing poor water quality or poor water output.




1. Remove the water storage top cover and clean the top cover dirt




2. Gently remove the filter element and filter groove




3. Clean the filter element tank to remove hair dirt



4. Clean the water pump to remove the hair dirt in the crevice



5. Clean the inner wall of the water storage bucket and dry the outer wall of moisture



6. When the filter groove is installed back on the top cover, check whether the bayonet is close

### Matters needing attention

1. Be sure to disconnect the power supply before cleaning.
2. Do not soak the body of the water dispenser and the power adapter in water.
3. For the first use, you need to clean the inside of the water storage bucket, the water storage top cover and the filter element tank with water.
4. There may be a little powder attached to the filter element when it leaves the factory, which is a normal phenomenon and can be rinsed with clean water.
5. Please clean or replace the water storage bucket, water storage top cover, filter element tank, filter element and silicone aqueduct regularly according to the water quality and pet drinking habits. It is recommended to clean at least once a week and change the water thoroughly to prevent dirt from clogging the filter tank and causing water quality abnormal phenomena such as deterioration or poor water flow.
6. The filter element is recommended to be replaced once a month.

### warn

1. This product and all accessories are not edible.
2. Please use it in a dry indoor environment.
3. Do not place this product in a high place.
4. When using, keep the machine horizontal, do not tilt or overturn.
5. Do not add hot water or boiling water to the water storage bucket, so as not to scald and deform and affect the use.
6. Please do a good job of shielding and storing the power cord to avoid leakage and damage caused by pet bites. The power supply provides a safe working voltage, which will not endanger the safety of pets and their owners.
7. Do not disassemble or repair the device without authorization, so as not to affect the after-sale service.
8. Do not use any accessories not provided by the original factory, we are only responsible for the performance and safety of the accessories provided by the official.

### FAQ

- Q. How often does pet fountain change the water and how often we need to clean it?  
A. According to the water quality and pet drinking habits. It is recommended to replace or add water every 2-3 days; it is recommended to clean at least once a week (including water tank, top cover, filter slot, filter), and completely change the water to prevent fouling from clogging the filter slot, resulting in abnormal water quality.  
Do not use hot water or boiling water when cleaning.
- Q. What kinds of water should be used in the pet fountain?  
A. It is recommended to use pure water or mineral water.
- Q. How often does filter core need to be replaced?  
A. The filter core is recommended to be replaced once a month to maintain a good filter effect.
- Q. Does the pet fountain consume lots of power? Is there any noise?  
A. It has low working power (MAX4.5W) and consumes about 1 kWh in 10 days. The product adopts silent pump and noise reduction design, working without noise. (There is natural water sounds to attract pets to drink plenty of water.)
- Q. Is there any safety hazard when the power cable of the pet fountain is bitten by a pet?  
A. The power supply adopts 5V low voltage and 0.6A low current to ensure the safety of pets. Friendly reminder: use broken power core will have a hazards of pets eating, please replace it in time.
- Q. What are the most suitable cats and dogs for pet fountain?  
A. Suitable for adult cats and small medium dogs.
- Q. What is the reason that the pet fountain does not work after it is powered on?  
1. Check if the power cord is damaged;  
2. Check if the bottom power connector is loose;  
3. Check if the water pump outlet and hose connection are loose.

尺寸：100x127mm  
材质：128g铜板纸

### Repair form

Commodity maintenance record -----

Repair time -----

Repair failure -----

cause of issue -----

Troubleshooting -----

Return certificate -----

Validation date -----

Original device ID -----

New device ID -----

Signature of maintenance personnel -----

Maintenance department stamp -----